Quick Guide

Jewelry Balances JL-GE Models Adjustments



Operation Keys

Indicates active application Weighing-in aid Indicates unstable values $\begin{array}{c} & & & \\ & & & & \\ & & & $			
Key Functions			
No.	Кеу	Press briefly (less than 1.5 s)	Press and hold (longer than 1.5 s)
1	⊟ ՃՃ/F	 Printout display value Transmit data To navigate backwards in the menu or menu selection Decrease parameters in menu or applications 	 Open the application list and scroll among the weighing applications in certain sequence for selecting an application Exits an active application and returns to the selection for weighing mode
2	→0 ← c	Zero setting	 Cancel or leave menu without saving One step back in the menu Cancel or leave application setting
3	→⊺ ← ⊍	Tare Switch on	Switch off
4	S d	 With entries, scroll down To navigate forward menu topics or menu selections To toggle between unit 1, recall value (if selected), unit 2 (if different from unit 1) and the application unit (if any) Increase parameters in menu or applications 	Execute predefined adjustment (calibration) procedure
5	← Menu	Enter or leave menu selection To enter application parameter and switch to next parameter To store parameter	Enter or leave menu (parameter settings)



Menu Map



Advanced Menu Selection Topic ENI' IRON. 🖵 573. 🔤 UNSTR3. STRBLE ______ ארך ארים אר ERL]876.FRM 🛶]].MM.Y 📾 MM/]]/Y ₩-MM-]] J.MMM Y МММ]У TIME.FRM 🖵 24:MM 🔤 12:MM 24 MM 12,MM RECALL ┙ OFF 1..... ON STRN]]]Y ← - <u>50</u> <u>⇒</u> R.ON R.OFF 3.L. ON 🖷 BLIGHT 🖵 B.L. OFF ○ R.ZER0 ← **ON** OFF OFF SRV. IEON 🖬 [***/ ΠN _____SRV.].RST ←____ N07 YE57

Legend

- Factory setting 1444
- Only those weight units allowed by the appropriate 1 national legislation are selectable
- \odot Not available with approved models Not available with approved models with $\mathbf{e} = \mathbf{d}$ ۲
- N Settings are automatically set for the 2nd display
- \diamond
- Only visible if "PRINTER" is selected \Diamond Only visible if "HOST" is selected
- ◈ Only visible if "PC-DIR" is selected
- ۲ Only visible if "PRT.AUTO" is selected



www.mt.com/jewelry

For more information

n 1 3 0 6

Mettler-Toledo AG Laboratory & Weighing Technologies CH-8606 Greifensee, Switzerland

Subject to technical changes © Mettler-Toledo AG 11/2014 30130465A en